

Multi-Tilt Mechanism

Models 8384, 8385



Multi-Tilt Mechanism

To tilt chair, pull lever up to desired position, push lever down to lock.

Height Adjustment Control

To raise chair shift body weight up, pull lever up. To lower chair, remain seated and pull lever up.

Back Angle Adjustment

Pull lever up, adjust back angle, and push lever down to lock in position.

Seat Angle Adjustment

Tilt chair back, flip lever back for forward angle, tilt chair back, flip lever forward for back angle.

Back Height Adjustment

Lift back to desired position. To lower, pull the chair back all the way up and lower to seat.

Arm Height Adjustment

Press button under arm cap, adjust height and release button.

Chairs with optional arm width adjustment – Push lever forward on underside of seat near arm, adjust width of arm, push lever back to lock.

Chairs with optional seat slider

Pull knob out, shift seat forward or back to desired position and release knob to lock.

Tension Control Knob

Turn clockwise to increase tension and counterclockwise to decrease tension.